



# RynoWorx

## RynoWorx RA-PPT-0001

### 2 Gallon Pour Pot Assembly Instructions

#### RECOMMENDED TOOLS

- #2 Phillips Screw Driver
- Pipe Wrench



① Screw the connector to the bottom of the "L" plunger handle.

② Install the "L" plunger handle into the main handle from the bottom, inserting the short part of the handle first. Finish by inserting the long part of the handle into the lower guide hole.

Screw the long rod into the plunger handle connector using the **short thread** of the rod.



Screw the plunger into the **long thread** of the long rod.



③ Short Thread

④ Long Thread

⑤ Slide the handle and plunger assembly into the pour pot, then secure with the supplied screws, lock washers and wing nuts. Tighten screws with a Phillips head screwdriver until firmly secure.

**Tip 1:** Lock washers should always be placed closest to the wing nuts.

**Tip 2:** If no tools are available for assembly, secure wingnuts on the outside and tighten by hand.



⑥ Install the 90° elbow onto the bottom of the pour pot. **Note:** A pipe wrench may be required to get the final turn.

⑦ Install the optional reducer bushing for less flow.

